



20103-2018 Ford Focus ST/RS Cable Reset Instructions

This procedure should be performed after the installation of your JBR Short Shifter.

1. Put the car in neutral and engage the emergency brake.
2. Remove the air filter box and locate the shifter cables.
3. Slide the white or orange clip towards the passenger side as shown.



4. Move the gearshift select cable arm at the transmission back and forth to verify free motion.



5. Place the gear shift lever in 4th gear and have someone hold the lever tight to the PASSENGER side. If no one is available, use something a bungee cord or similar means.
6. Return the clip moved in step 4 to its original position.

This completes the cable reset procedure.